

BRAND	MODEL	ENGINE	From	Till	Kw	HP	CCC
CITROEN	JUMPER (230L)	1.9 D	1994/02	2002/04	51	69	1905
CITROEN	JUMPER (230L)	2.5 D	1994/03	2002/04	63	86	2446
CITROEN	JUMPER (230L)	1.9 TD	1994/03	2002/04	66	90	1905
CITROEN	JUMPER (230L)	1.9 TD	1994/03	2002/04	68	92	1905
CITROEN	JUMPER (230L)	2.5 TD	1994/03	2002/04	76	103	2446
CITROEN	JUMPER (230L)	2.0	1994/03	2002/04	80	109	1998
CITROEN	JUMPER (230L)	2.0 4x4	1996/10	2002/01	80	109	1998
CITROEN	JUMPER (230L)	2.5 TDi	1996/12	2000/11	79	107	2446
CITROEN	JUMPER (230L)	2.8 D	1999/01	2002/02	64	87	2798
CITROEN	JUMPER (230L)	1.9 D	1999/07	2002/04	50	68	1905
CITROEN	JUMPER (230L)	2.5 D 4x4	2000/03	2002/04	63	86	2446
CITROEN	JUMPER (230L)	2.8 HDi	2000/09	2002/04	94	128	2798
CITROEN	JUMPER (230L)	2.8 HDi 4x4	2000/09	2002/04	94	128	2798
CITROEN	JUMPER (230L)	2.0 HDi	2001/11	2002/04	62	84	1997
CITROEN	JUMPER (244)	2.0 HDi	2002/04		62	84	1997
CITROEN	JUMPER (244)	2.2 HDi	2002/04		74	101	2179
CITROEN	JUMPER (244)	2.0	2002/04		81	110	1998
CITROEN	JUMPER (244)	2.8 HDi 4x4	2002/04		94	128	2798
CITROEN	JUMPER (244)	2.8 HDi	2002/04		94	128	2798
CITROEN	JUMPER (244)	2.0 bivalent	2003/02		81	110	1998
CITROEN	JUMPER (244)	2.8 HDi	2004/05		107	146	2798
CITROEN	JUMPER (230)	2.5 D	1994/03	2002/04	63	86	2446
CITROEN	JUMPER (230)	1.9 TD	1994/03	2002/04	66	90	1905
CITROEN	JUMPER (230)	1.9 TD	1994/03	2002/04	68	92	1905
CITROEN	JUMPER (230)	2.5 TD	1994/03	2002/04	76	103	2446
CITROEN	JUMPER (230)	2.0	1994/03	2002/04	80	109	1998
CITROEN	JUMPER (230)	2.5 TDi	1996/12	2002/04	79	107	2446
CITROEN	JUMPER (230)	2.8 D	1999/01	2002/02	64	87	2798
CITROEN	JUMPER (230)	2.5 D 4x4	2000/03	2002/04	63	86	2446
CITROEN	JUMPER (230)	2.5 TDi 4x4	2000/03	2002/04	79	107	2446
CITROEN	JUMPER (230)	2.8 HDi	2000/09	2002/04	94	128	2798
CITROEN	JUMPER (230)	2.8 HDi	2000/10	2002/01	93	126	2798
CITROEN	JUMPER (244)	2.2 HDi	2002/02	2006/06	74	101	2179
CITROEN	JUMPER (244)	2.8 HDi 4x4	2002/02	2006/06	94	128	2798
CITROEN	JUMPER (244)	2.0 HDi	2002/04		62	84	1997
CITROEN	JUMPER (244)	2.2 HDi	2002/04		74	101	2179
CITROEN	JUMPER (244)	2.8 HDi	2002/04		94	128	2798
CITROEN	JUMPER (244)	2.8 HDi	2004/05		107	146	2800
FIAT	DUCATO (230L)	1.9 D	1994/03	2002/04	51	69	1929
FIAT	DUCATO (230L)	1.9 TD	1994/03	2002/04	60	82	1929
FIAT	DUCATO (230L)	2.5 D	1994/03	2002/04	62	84	2500
FIAT	DUCATO (230L)	2.5 TDI	1994/03	2002/04	80	109	2500
FIAT	DUCATO (230L)	2.0	1994/03	2002/04	80	109	1998
FIAT	DUCATO (230L)	2.5 TDI	1994/03	2002/04	85	116	2500
FIAT	DUCATO (230L)	1.9 TD CAT	1994/08	2002/04	59	80	1929
FIAT	DUCATO (230L)	2.0 4x4	1994/11	2002/04	80	109	1998
FIAT	DUCATO (230L)	2.8 TDI	1997/10	2002/04	90	122	2800
FIAT	DUCATO (230L)	1.9 D	1998/04	2002/04	50	68	1905

FIAT	DUCATO (230L)	1.9 TD	1998/04	2002/04	66	90	1905
FIAT	DUCATO (230L)	1.9 TD	1998/05	2001/11	59	80	1905
FIAT	DUCATO (230L)	2.8 D	1998/05	2002/04	64	87	2800
FIAT	DUCATO (230L)	2.5 TDI 4x4	1998/05	2002/04	85	116	2500
FIAT	DUCATO (230L)	2.8 D 4x4	1998/08	2002/04	64	87	2800
FIAT	DUCATO (230L)	2.8 TDI 4x4	1999/06	2002/04	90	122	2800
FIAT	DUCATO (230L)	2.8 JTD	2000/11	2002/04	94	128	2798
FIAT	DUCATO (230L)	2.8 JTD 4x4	2000/11	2002/04	94	128	2798
FIAT	DUCATO (230L)	2.0 JTD	2001/10	2002/04	62	84	1997
FIAT	DUCATO (244)	2.0 JTD	2002/04		62	84	1997
FIAT	DUCATO (244)	2.3 JTD	2002/04		81	110	2286
FIAT	DUCATO (244)	2.0	2002/04		81	110	1998
FIAT	DUCATO (244)	2.8 JTD	2002/04		94	128	2798
FIAT	DUCATO (244)	2.0 4x4	2002/05	2006/07	81	110	1998
FIAT	DUCATO (244)	2.8 JTD 4x4	2002/07		94	128	2798
FIAT	DUCATO (244)	2.0 Bipower	2002/11		81	110	1998
FIAT	DUCATO (244)	2.8 TD	2003/11	2006/07	90	122	2799
FIAT	DUCATO (244)	2.8 TD 4x4	2003/11	2006/07	90	122	2799
FIAT	DUCATO (244)	2.8 JTD Power	2004/05		107	146	2800
FIAT	DUCATO (230)	1.9 D	1994/03	2002/04	51	69	1929
FIAT	DUCATO (230)	1.9 TD	1994/03	2002/04	60	82	1929
FIAT	DUCATO (230)	2.5 D	1994/03	2002/04	62	84	2500
FIAT	DUCATO (230)	2.5 D 4x4	1994/03	2002/04	62	84	2500
FIAT	DUCATO (230)	2.5 TDI	1994/03	2002/04	80	109	2500
FIAT	DUCATO (230)	2.0	1994/03	2002/04	80	109	1998
FIAT	DUCATO (230)	2.5 TDI	1994/03	2002/04	85	116	2500
FIAT	DUCATO (230)	1.9 TD CAT	1994/08	2002/04	59	80	1929
FIAT	DUCATO (230)	2.8 D	1998/02	2002/04	64	87	2800
FIAT	DUCATO (230)	1.9 D	1998/04	2002/04	50	68	1905
FIAT	DUCATO (230)	1.9 TD	1998/04	2002/04	66	90	1905
FIAT	DUCATO (230)	1.9 TD	1998/05	2001/11	59	80	1905
FIAT	DUCATO (230)	2.5 TDI 4x4	1998/06	2002/04	85	116	2500
FIAT	DUCATO (230)	2.8 TDI	1998/12	2002/04	90	122	2800
FIAT	DUCATO (230)	2.8 JTD	2000/11	2002/04	94	128	2798
FIAT	DUCATO (230)	2.8 JTD	2001/03	2002/04	94	128	2799
FIAT	DUCATO (244)	2.0 JTD	2002/04	2006/07	62	84	1997
FIAT	DUCATO (244)	2.0	2002/04	2006/07	81	110	1998
FIAT	DUCATO (244)	2.3 JTD	2002/04	2006/07	81	110	2286
FIAT	DUCATO (244)	2.8 JTD	2002/04	2006/07	94	128	2798
FIAT	DUCATO (244)	2.8 JTD 4x4	2002/10	2006/07	94	128	2798
FIAT	DUCATO (244)	2.8 JTD 4x4	2003/11	2006/07	90	122	2799
FIAT	DUCATO (244)	2.8 JTD	2003/11	2006/07	90	122	2799
FIAT	DUCATO (244)	2.8 JTD Power	2004/05	2006/07	107	146	2800
PEUGEOT	BOXER (230L)	1.9 D	1994/03	2002/04	51	69	1905
PEUGEOT	BOXER (230L)	2.5 D	1994/03	2002/04	63	86	2446
PEUGEOT	BOXER (230L)	1.9 TD	1994/03	2002/04	68	92	1905
PEUGEOT	BOXER (230L)	2.5 TD	1994/03	2002/04	76	103	2446
PEUGEOT	BOXER (230L)	2.0 i	1994/06	2002/04	80	109	1998
PEUGEOT	BOXER (230L)	2.5 TDI	1997/01	2002/04	79	107	2446
PEUGEOT	BOXER (230L)	2.5 DT	1997/10	2001/11	62	84	2499

PEUGEOT	BOXER (230L)	2.8 D	1999/01	2002/02	64	87	2798
PEUGEOT	BOXER (230L)	1.9 D	1999/07	2002/04	50	68	1905
PEUGEOT	BOXER (230L)	2.5 D 4x4	1999/07	2002/04	63	86	2446
PEUGEOT	BOXER (230L)	1.9 TD	1999/07	2002/04	66	90	1905
PEUGEOT	BOXER (230L)	2.5 TDi 4x4	1999/07	2002/04	79	107	2446
PEUGEOT	BOXER (230L)	2.8 HDi	2000/10	2001/11	93	126	2798
PEUGEOT	BOXER (230L)	2.8 HDi 4x4	2000/10	2002/04	94	128	2798
PEUGEOT	BOXER (230L)	2.8 HDi	2000/11	2002/04	94	128	2798
PEUGEOT	BOXER (230L)	2.0 HDi	2001/08	2002/04	62	84	1997
PEUGEOT	BOXER (244)	2.0 BiFuel	2001/12	2006/06	81	110	1998
PEUGEOT	BOXER (244)	2.0 HDi	2002/04		62	84	1997
PEUGEOT	BOXER (244)	2.2 HDi	2002/04		74	101	2179
PEUGEOT	BOXER (244)	2.0	2002/04		81	110	1998
PEUGEOT	BOXER (244)	2.8 HDi 4x4	2002/04		94	128	2798
PEUGEOT	BOXER (244)	2.8 HDi	2002/04		94	128	2798
PEUGEOT	BOXER (244)	2.8 HDi	2004/04		107	146	2798
PEUGEOT	BOXER (244)	2.0 BiFuel	2001/12	2006/06	81	110	1998
PEUGEOT	BOXER (244)	2.8 TD	2001/12	2005/03	90	122	2798
PEUGEOT	BOXER (244)	2.0 HDi	2002/04		62	84	1997
PEUGEOT	BOXER (244)	2.2 HDi	2002/04		74	101	2179
PEUGEOT	BOXER (244)	2.8 HDi 4x4	2002/04		94	128	2798
PEUGEOT	BOXER (244)	2.8 HDi	2002/04		94	128	2798
PEUGEOT	BOXER (244)	2.8 HDi	2004/04		107	146	2798
PEUGEOT	BOXER (ZCT_)	2.5 D	1994/03	2002/04	63	86	2446
PEUGEOT	BOXER (ZCT_)	2.5 TD	1994/03	2002/04	76	103	2446
PEUGEOT	BOXER (ZCT_)	1.9 TD	1994/06	2002/04	66	90	1905
PEUGEOT	BOXER (ZCT_)	2.0 i	1994/06	2002/04	80	109	1998
PEUGEOT	BOXER (ZCT_)	1.9 TD	1994/07	2002/04	68	92	1905
PEUGEOT	BOXER (ZCT_)	2.5 TDi	1997/01	2002/04	79	107	2446
PEUGEOT	BOXER (ZCT_)	2.8 D	1999/01	2002/02	64	87	2798
PEUGEOT	BOXER (ZCT_)	2.5 D 4x4	1999/07	2002/04	63	86	2446
PEUGEOT	BOXER (ZCT_)	2.5 TDi 4x4	1999/07	2002/04	79	107	2446
PEUGEOT	BOXER (ZCT_)	2.8 HDi	2000/10	2001/11	93	126	2798
PEUGEOT	BOXER (ZCT_)	2.8 HDi	2000/11	2002/04	94	128	2798
PEUGEOT	BOXER (ZCT_)	2.0	2001/12	2002/04	81	110	1998